

CP88 Voice List

Current as of 1.40 Firmware

#	Section	Display Category	No.	Display Name	Description/Instrument Sample source	CC No.	Added in Firmware
1	PIANO	GRAND PIANO	01	CFX	Yamaha 9' CFX grand	1	1.00
2			02	IMPERIAL	Bosendorfer 9.5' Imperial 290 grand	2	1.00
3			03	S700	Yamaha S700 grand	3	1.00
4			04	DIGI PIANO		4	1.00
5			05	C7	Yamaha C7 grand	58	1.10
6			06	CF3	Yamaha CF3 grand	92	1.30
7			07	NASHVILLE CF3		95	1.40
8			08	LIVE CF3		96	1.40
9		UPRIGHT PIANO	01	U1	Yamaha U1 upright	5	1.00
10			02	SU7	Yamaha SU7 upright	6	1.00
11		CP	01	CP80 1	Yamaha CP80 electro-acoustic piano	7	1.00
12			02	CP80 2		8	1.00
13		SPECIAL PIANO	01	PIANO STRINGS		9	1.00
14			02	PIANO SYNTH		10	1.00
15	E. PIANO	RD	01	78RD	RD = Fender Rhodes electric pianos from various years	11	1.00
16			02	75RD FUNKY		12	1.00
17			03	73RD		13	1.00
18			04	67RD DARK		59	1.10
19			05	67RD BRIGHT		60	1.10
20			06	73RD STUDIO		93	1.30
21			07	74RD STAGE		94	1.30
22		WR	01	WR WARM	Wr = Wurlitzer electric pianos	14	1.00
23			02	WR BRIGHT		15	1.00
24			03	WR WIDE		61	1.10
25		CLV	01	CLAVI B	CLV = Hohner Clavinet keyboards	16	1.00
26			02	CLAVI S		17	1.00
27			03	HARPSICHORD		18	1.00
28		DX	01	DX LEGEND	DX = Yamaha DX7 series FM synths	19	1.00
29			02	DX WOODY		20	1.00
30			03	DX FTINE		21	1.00
31			04	DX 7 II		22	1.00
32			05	DX MELLOW		23	1.00

CP88 Voice List

Current as of 1.40 Firmware

33			06	DX CRISP		24	1.00
34	SUB	PAD/STRINGS	01	MELLOW PAD		25	1.00
35			02	SPECTRUM		26	1.00
36			03	BACK PAD		27	1.00
37			04	AIR CHOIR		28	1.00
38			05	NATURAL STR		29	1.00
39			06	WARM STRINGS		30	1.00
40			07	OB STRINGS		31	1.00
41			08	SECTION STR		32	1.00
42			09	FAT SAW PAD		62	1.20
43			10	NOBLE PAD		63	1.20
44			11	POP PAD		64	1.20
45			12	ANALOG PAD		65	1.20
46			13	ITOPIA		66	1.20
47			14	MARCATO STR		67	1.20
48			15	SLOW STR		68	1.20
49			16	TAPE STR		69	1.20
50			17	OCT SYN STR		70	1.20
51			18	AMGEL PAD		97	1.40
52			19	MYSTIC PAD		98	1.40
53			20	JP STRINGS		99	1.40
54			21	POP SYN STR		100	1.40
55			22	FAST STRINGS		101	1.40
56			23	PIZZICATO		102	1.40
57		ORGAN	01	BRIGHT BARS	Hammond B3 organ	33	1.00
58	02		CLICK ORGAN	34		1.00	
59	03		DRAW ORGAN 1	35		1.00	
60	04		ALL BARS OUT	36		1.00	
61	05		DRAW ORGAN 2	37		1.00	
62	06		60S COMBO	38	1.00		
63	07		COMPACT	39	1.00		
64	08		PANTHER	40	1.00		
65	09		PIPE ORGAN 1	41	1.00		
66	10		PIPE ORGAN 2	42	1.00		

CP88 Voice List

Current as of 1.40 Firmware

67			11	ACCORDION		103	1.40
68		CHROMATIC PERC.	01	GLOCKEN	Glockenspiel	43	1.00
69			02	VIBRAPHONE		44	1.00
70			03	XYLOPHONE		45	1.00
71			04	MARIMBA		46	1.00
72			05	BRIGHTNESS		47	1.00
73			06	JAZZ VIBES		71	1.20
74			07	MARIMBA 2		72	1.20
75			08	KALIMBA		73	1.20
76			09	HEAVEN BELL		74	1.20
77			10	NICE BELL		48	1.00
78			11	STACK BELL		49	1.00
79		OTHERS	01	SYN LEAD 1		50	1.00
80			02	SYN LEAD 2		51	1.00
81			03	SYN BASS		52	1.00
82			04	E. BASS		53	1.00
83			05	A. BASS		54	1.00
84			06	STEEL GT		55	1.00
85			07	CLEAN GT		56	1.00
86			08	SYN BRASS		57	1.00
87			09	SINE LEAD		75	1.00
88			10	SYNC SAW		76	1.20
89			11	DIRTY HOOK		77	1.20
90			12	CLASSIC MINI		78	1.20
91			13	FUNKY MINI		79	1.20
92			14	NU MINI		80	1.20
93			15	80S POP BASS		81	1.20
94			16	SUB BASS		82	1.20
95			17	UNISON BASS		83	1.20
96			18	FINGER BASS		84	1.20
97			19	BRASS		85	1.20
98			20	SYN BRASS 2		86	1.20
99			21	0B BRASS 1		87	1.20
100			22	0B BRASS 2		88	1.20

CP88 Voice List

Current as of 1.40 Firmware

101			23	JAZZ FLUTE		89	1.20
102			24	TAPE FLUTE		90	1.20
103			25	HARMONICA		91	1.20
104			26	CLASSIC GT		104	1.40
105			27	STEEL GT 2		104	1.40
106			28	ST. BRASS		106	1.40